

MIDIcreator

Information Sheet

Sensor: Switch Adaptors **Reference No:** NA

Specification:

- Switched sensor
 - Adaptor cable
- Physical
 - 3.5mm or ¼" jack socket

Use: Switch adaptors allow standard assistive technology style switches to be plugged into MIDIcreator.

Trouble Shooting: Ensure the switch is plugged firmly into the switch adaptor.

Check the following:

- Check the lead is fully plugged in.
- Check both green LEDs on MIDIcreator are on.
- Check MIDI lead and sound module.
- Check red LED on MIDIcreator flickers when sensor is operated.
- Check for possible broken wires.
- Check usage is correct.

Care:

- Sensitive electronic equipment, do not subject to wet or damp conditions.
- Pull plugs out of MIDIcreator by the plug body, not the cable.
- Do not use water, scouring pads or solvents for cleaning sensors.

Safety Tips: There are no electrical or health hazards using any of the sensors but care should be taken with the operating environment:

- Ensure the floor area is clear behind the operator so as not to trip over anything when moving backwards.
- Ensure cables to MIDIcreator are placed so that people cannot trip over them.
- Always turn off the mains wall socket before plugging or unplugging the MIDIcreator power supply.
- Only use the sensors for their correct purpose.