

MIDIcreator

Information Sheet

Sensor: MIDIfloorpad **Reference No:** G00296

Specification:

- Switched sensor
 - Applied pressure
 - Contact, feet, rear or hand
- Electrical
 - Nominal current: 0.10mA
- Physical
 - Cable length: 3 metres
 - Soft plastic
 - Size: 595 x 170 x 3mm

Use: Triggers a sound by rolling or walking on this floor pad. Can be used with any of the 16 MIDIcreator inputs, provided a switched sound has been assigned.

Trouble Shooting: A reasonable amount of pressure is required to operate i.e. 10s of kilos. A child may trigger the pad only when jumping on the pad.

Check the following:

- Check the lead is fully plugged in.
- Check both green LEDs on MIDIcreator are on.
- Check MIDI lead and sound module.
- Check red LED on MIDIcreator flickers when sensor is operated.
- Check for possible broken wires.
- Check usage is correct.

Care:

- Sensitive electronic equipment, do not subject to wet or damp conditions.
- Pull plugs out of MIDIcreator by the plug body, not the cable.
- Do not use water, scouring pads or solvents for cleaning sensors.

Safety Tips: There are no electrical or health hazards using any of the sensors but care should be taken with the operating environment:

- Ensure the floor area is clear behind the operator so as not to trip over anything when moving backwards.
- Ensure cables to MIDIcreator are placed so that people cannot trip over them.
- Always turn off the mains wall socket before plugging or unplugging the MIDIcreator power supply.
- Only use the sensors for their correct purpose.